SPEC SHEET + MEASUREMENTS

PORT AUTHORITY

Port Authority ® Tall Long Sleeve Carefree Poplin Shirt.

TW100

Product photo



Lightweight and breathable, our cotton-rich shirts keep their professional edge thanks to a stain-release finish, which releases stains during washing. Budget-friendly and durable, these virtually carefree shirts feature an Easy Care blend and finish. They also color-coordinate with our Core Classic Pique styles for seamless uniforming.

- 3.3-ounce, 55/45 cotton/poly
- Easy Care
- Stain release
- Breathable
- Dyed-to-match buttons
- Button-down collar
- Back box pleat
- Left chest pocket
- Rounded adjustable cuffs

Sketches



front



back

CARE INSTRUCTIONS

Machine wash cold with like colors. Only non-chlorine bleach if needed. Tumble dry low. Warm iron if needed

SPEC SHEET + MEASUREMENTS

PORT AUTHORITY

Port Authority ® Tall Long Sleeve Carefree Poplin Shirt.

TW100

PRODUCT MEASUREMENTS

	LT	XLT	2XLT	3XLT	4XLT
Chest Width	24 1/2	26	27 1/2	29 1/2	31 1/2
Body Length at Back	35	36	37	37 1/2	38
Sleeve Length	37 1/2	38 1/4	39	39 3/4	40 1/2
Pocket Height	5 3/8	5 3/8	5 3/8	5 3/8	5 3/8
Pocket Width	4 7/8	4 7/8	4 7/8	4 7/8	4 7/8
Neck	18	19	19 3/4	20 1/2	21 1/4

Chest Width: Measured across the chest one inch below armhole when laid flat.

Body Length at Back: Measured from high point shoulder to finished hem at back.

Sleeve Length: Start at center of neck and measure down shoulder, down sleeve to hem.

Pocket Height: Measure from top to bottom at center.

Pocket Width: Measure from side to side at top edge.

Neck: Measured from center of button to center of buttonhole.

SPEC SHEET + MEASUREMENTS

PORT AUTHORITY

Port Authority ® Tall Long Sleeve Carefree Poplin Shirt.

TW100

SIZE CHARTS

	LT	XLT	2XLT	3XLT	4XLT
Chest	41-43	44-46	47-49	50-53	54-57
Neck	18	19	19 3/4	20 1/2	21 1/4
Arm	36 1/2	38	39	40	41

SPEC SHEET + MEASUREMENTS

PORT AUTHORITY

Port Authority ® Tall Long Sleeve Carefree Poplin Shirt.

TW100

HOW TO MEASURE

NECK

Measure around the fullest part of the neck at the base.

CHEST

Measure under the arm and around the fullest part of the chest with arms down, keeping tape horizontal.

NECK

Measure around the fullest part of the neck at the base.

CHEST

Measure under the arm and around the fullest part of the chest with arms down, keeping tape horizontal.

ARM

Place hand on hip. Start at the center of the back of the neck and measure across the shoulder, to the elbow, and then down to the wrist.

NECK

Measure around the fullest part of the neck at the base.

CHEST

Measure under the arm and around the fullest part of the chest with arms down, keeping tape horizontal.

ARM

Place hand on hip. Start at the center of the back of the neck and measure across the shoulder, to the elbow, and then down to the wrist.

NECK

Measure around the fullest part of the neck at the base.

SPEC SHEET + MEASUREMENTS

PORT AUTHORITY

Port Authority ® Tall Long Sleeve Carefree Poplin Shirt.

TW100



Measure under the arm and around the fullest part of the chest with arms down, keeping tape horizontal.

COLORS

Deep Black	True Royal	White
BLACK C	7687C	