

SPEC SHEET + MEASUREMENTS



The North Face® Women's Ridgewall Soft Shell Jacket . NF0A3LGY

Product photo



Constructed of an abrasion- and wind-resistant outer shell with a warm, technical gridded fleece interior, the Ridgewall is the ultimate mid-weight option for active outdoor adventures.

- 306 g/m2 WindWall™—100% recycled post-consumer polyester with non-PFC durable water-repellent (DWR) finish (solid)
- 316 g/m2 WindWall™—100% polyester with non-PFC durable water-repellent (DWR) finish (heather)
- Highly wind-resistant with wind permeability at less than 10 CFM (0 CFM is 100% windproof)
- Brushed micro-gridded fleece interior
- Non-PFC durable water-repellent (DWR) finish
- Reverse-coil center front zipper and hand pockets
- Interior hem cinch-cord
- Embroidered The North Face logo on left sleeve and right back shoulder

BENEFITS

DURABLE WATER-REPELLENT: DWR is applied to the face of the fabric to provide the first line of defense against wet weather.

WIND PROTECTION: WindWall™ fabrics greatly reduce the effects of wind chill while providing flexibility and breathability to stay comfortable without overheating.

CARE INSTRUCTIONS

Machine wash separately on delicate cycle in warm water. Secure and close all zippers, and hook and loop closures before wash. Turn garment inside out. Do not use bleach or softeners. Tumble dry low heat or for best results line dry. Do not iron or dry clean.

Sketches



front



back

SPEC SHEET + MEASUREMENTS



The North Face® Women's Ridgewall Soft Shell Jacket . NF0A3LGY

PRODUCT MEASUREMENTS

	S	M	L	XL	2XL
Size	4/6	8/10	12/14	16/18	20/22
Bust	18 1/4	19 1/2	21	22 3/4	24 1/2
Body Length at Back	25 7/8	26 1/2	27 3/8	28 1/4	29 1/8
Sleeve Length	32 1/2	33	33 3/4	34 1/2	35 1/4

Bust: Measured across the chest one inch below armhole when laid flat.

Body Length at Back: Measured from high point shoulder to finished hem at back.

Sleeve Length: Start at center of neck and measure down shoulder, down sleeve to hem.

SIZE CHARTS

	S	M	L	XL	2XL
Size	4/6	8/10	12/14	16/18	20/22
Bust	33-35	36-38	39-41	42-44	45-48

SPEC SHEET + MEASUREMENTS



The North Face® Women's Ridgewall Soft Shell Jacket . NF0A3LGY

HOW TO MEASURE



BUST

Measure under the arm and around the fullest part of the bust with arms down, keeping tape horizontal.

COLORS



TNF Black
BLACK C



TNF
Blackberry
Wine
519C



TNF Dark
Grey Heather
BLACK 7C